S3 - Record & Replay video

- record.py record encoded streams from all devices and synchronize them
- Recordings will be saved in specified folder (with -p, default folder is recordings/)
 - Recordings saved as MJPEG or H265. You can manually use ffmpeg to convert these .mjpeg to .mp4
 - Using PyAv, it saves encoded streams into __mp4 containers. Allows to watch videos with a standard video player

Steps to record

- navigate to /Desktop/LuxonisCamera/depthai-experiments/gen2-record-replay
- To start recording run: sudo python3 record.py -save color left right disparity depth fps 30 -q medium
 - To start recording run: sudo python3 record.py -save color left right disparity -fps 30 -q medium
 - recording will automatically save to /Desktop/LuxonisCamera/depthaiexperiments/gen2-record-replay/recordings
 - -save specifys what streams to save (color, left, and right are default when not specified)
 - depth may not work together with other streams
 - depth produces a .bag file that can be viewed using <u>Intel realsense</u>
 - Fps specifys frames per second, (Max is 60)
 - q specifys quality (BEST, HIGH, MEDIUM, LOW)
- To stop recording, press ctrl-c
- To view replay of recording run: sudo python3 replay.py -p [FOLDER PATH]